

11. TROUBLE SHOOTING

ENGINE

Trouble	Probable Causes	Remedies
Engine does not start	<ol style="list-style-type: none"> Excessive wear of piston ring or cylinder Seized valve in valve guide Seized piston Faulty valve timing Low or lack of compression pressure <ul style="list-style-type: none"> Pressure leak Blown out cylinder head gasket Warped gasketing surface of the cylinder and cylinder head 	Replace Replace Replace Adjust Lap the valve to obtain good valve seating or replace Replace Repair or replace
Poor engine idling	Valve Mechanism <ol style="list-style-type: none"> Incorrect tappet clearance Low or lack of compression pressure Excessive valve guide clearance 	Adjust to standard value Repair Replace valve and guide
Loss of power	<ol style="list-style-type: none"> Valve sticking open Incorrect seating of valve Weak or broken valve spring Faulty valve timing Blown out cylinder head gasket Excessive wear of cylinder and piston Worn, weak or broken piston ring Loose spark plug 	Replace Lap valve Replace Check valve timing and adjust if necessary Replace Replace Replace Retighten
Overheating	<ol style="list-style-type: none"> Heavy carbon deposit on combustion chamber and piston head Lean fuel mixture Retarded ignition timing Low oil level, poor quality Extended operation in low gear 	Remove carbon Adjust the carburetor Adjust ignition timing Add good grade oil
Backfire	<ol style="list-style-type: none"> Incorrect seating of inlet valve Faulty valve timing Incorrect ignition timing Excessive spark plug gap Improper fuel 	Check the valve seating Adjust Adjust Adjust the gap to 0.024~0.028 in (0.6~0.7 mm) Replace
White exhaust smoke	<ol style="list-style-type: none"> Excessive wear of cylinder and piston Overfilled engine oil Excessively high oil pressure Poor quality oil 	Replace the piston Adjust the oil level Check the breather Replace with good quality oil
Black exhaust smoke	Rich fuel mixture	Adjust the carburetor

Trouble	Probable Causes	Remedies
Difficult gear shifting	<ol style="list-style-type: none"> 1. Improper clutch disengagement 2. Damaged gear or foreign object lodged in the gear 3. Gear shift fork inoperative 4. Incorrect operation of the gear shift drum stopper and change pedal 5. Mainshaft and countershaft out of alignment 6. High oil viscosity 	Adjust the clutch Replace the defective parts Repair or replace Repair or replace Repair or replace Change the oil
Excessive high gear noise	<ol style="list-style-type: none"> 1. Excessive gear backlash 2. Worn main and countershaft bearing 	Repair or replace Repair or replace
Gear slip out	<ol style="list-style-type: none"> 1. Worn fingers on gear shift fork 2. Worn gear dog hole 3. Worn spline 	Replace Replace Replace
Clutch slippage	<ol style="list-style-type: none"> 1. No play in the clutch lever 2. Weak or none uniform clutch pressure plate spring 3. Worn or glazed friction disc 	Adjust the clutch lever Replace the weak spring Replace
Poor clutch engagement	<ol style="list-style-type: none"> 1. Excessive play of clutch lever 2. Warped friction disc 3. Warped pressure plate 4. Bent main shaft 	Adjust clutch lever play Replace Replace Replace
Pedal does not return	<ol style="list-style-type: none"> 1. Faulty return spring 2. Unhook return spring 	Replace Hook return spring
Kick starter gear does not rotate	<ol style="list-style-type: none"> 1. Excessive wear of kick starter pawl 	Replace
Engine does not start	Carburetor <ol style="list-style-type: none"> 1. Choke fully open 2. Carburetor air screw improperly set 3. Air leaking into the cylinder head 4. Clogged carburetor slow jet 5. Clogged fuel valve or piping 6. Clogged vent hole in the fuel tank cap 7. No fuel in the tank 	Close choke Adjust air screw Retighten carburetor connecting tube Check, clean and retighten Disassemble and clean Disassemble and clean Fill tank with gasoline
Poor engine idling	Carburetor <ol style="list-style-type: none"> 1. Clogged or loose carburetor slow jet 2. Improper float level 3. Incorrect air screw adjustment 4. Carburetor linkage malfunction 5. Air leaks 	Check, clean and retighten Adjust Adjust Adjust Tighten all air passage connection
Improper running of engine	Carburetor <ol style="list-style-type: none"> 1. Jet size too small 2. Improper float level 3. Clogged carburetor main jet 4. Carburetor linkage malfunction 5. Air leaks 	Replace with larger size jet Adjust Clean and retighten Adjust Tighten all air passage connection

CHASSIS

Trouble	Probable Causes	Remedies
Heavy steering	<ol style="list-style-type: none"> 1. Steering stem excessively tightened 2. Damaged steering stem steel balls 3. Bent steering 4. Low front tire pressure 	Loosen the steering stem nut Replace Replace Add air to the specified pressure of 1.8 kg/cm ² (25.6 psi)
Front and rear wheel wobble	<ol style="list-style-type: none"> 1. Loose steering stem mounting bolt 2. Worn front and rear wheel bearings 3. Front or rear wheel runout or distorted 4. Loose spoke 5. Defective tire 	Retorque Replace bearing Repair or replace Retorque Replace
Soft suspension	<ol style="list-style-type: none"> 1. Loss of spring tension 2. Excessive load 	Replace
Hard suspension	<ol style="list-style-type: none"> 1. Ineffective front fork damper 2. Ineffective rear damper 	Repair Replace
Suspension noise	<ol style="list-style-type: none"> 1. Front case or rear damper rubbing 2. Interference between cushion case and spring 3. Faulty fork stopper rubber 4. Insufficient front fork oil 	Inspect cushion spring and case Repair or replace Replace Add damper oil
Defective brake	<ol style="list-style-type: none"> 1. Front brake fluid <ul style="list-style-type: none"> • Insufficient brake fluid • Air in the brake system • Worn brake pad • Worn piston • Worn or distorted front brake disc • Brake lever out of adjustment 2. Rear brake <ul style="list-style-type: none"> • Worn brake lining • Worn brake shoe or poor contacts • Worn brake cam • Wet brake from water or oil • Worn brake shaft • Brake pedal out of adjustment 	Add brake fluid Bleed brake system Replace pad Replace piston Replace disc Readjust Replace Replace Replace Clean Replace Readjust

ELECTRICAL

Troubles	Probable causes	Remedies
Engine does not start	<ol style="list-style-type: none"> 1. Battery <ul style="list-style-type: none"> • Discharged • Poor contact of battery terminals 2. Main switch <ul style="list-style-type: none"> • Open or shorted circuit, disconnected connections • Poor contact between main switch wire and wire harness 3. Ignition coil <ul style="list-style-type: none"> • Improperly insulated high tension coil • Open or shorted circuit in ignition coil 4. Contact breaker <ul style="list-style-type: none"> • Open circuit in the primary coil • Dirty ground point with oil or dust • Point gap out of adjustment • Improperly charged condenser 	<p>Recharge or replace</p> <p>Repair</p> <p>Repair</p> <p>Repair</p> <p>Replace</p> <p>Replace</p> <p>Repair</p> <p>Clean</p> <p>Readjust</p> <p>Replace</p>
Starting motor does not operate	<ol style="list-style-type: none"> 1. Defective battery 2. Poor contact of magnetic switch 3. Poor contact of starting motor carbon brush 	<p>Charge or replace</p> <p>Repair or replace</p> <p>Repair or replace</p>
Horn inoperative, poor sound or too weak sound	<ol style="list-style-type: none"> 1. Horn <ul style="list-style-type: none"> • Cracked diaphragm 2. Horn button <ul style="list-style-type: none"> • Poor grounding 3. Wiring <ul style="list-style-type: none"> • Poor contact 4. Adjusting screw <ul style="list-style-type: none"> • Out of adjustment 	<p>Replace</p> <p>Repair</p> <p>Repair</p> <p>Readjust</p>
Tail light and head light inoperative	<ol style="list-style-type: none"> 1. Fuse <ul style="list-style-type: none"> • Blown fuse or burnt bulb filament 2. Bulb <ul style="list-style-type: none"> • Burnt bulb filament 3. Switch <ul style="list-style-type: none"> • Poor contact of lighting switch 4. Wiring 	<p>Replace</p> <p>Readjust</p> <p>Readjust</p>
Stop light inoperative	<ol style="list-style-type: none"> 1. Bulb <ul style="list-style-type: none"> • Burnt or broken bulb filament 2. Front and tail stop light switch <ul style="list-style-type: none"> • Malfunction of switch 3. Wiring <ul style="list-style-type: none"> • Poor contact of leads 	<p>Replace</p> <p>Readjust</p> <p>Readjust</p>
Winker lamp blinks too fast or too slow	<ol style="list-style-type: none"> 1. Bulb <ul style="list-style-type: none"> • Blinks unusually fast: improperly connected relay 2. Wiring <ul style="list-style-type: none"> • Blinks too fast: bulb with unsuitable wattage • Blinks too slow: burnt or broken bulb 3. Defective relay 	<p>Replace</p> <p>Replace</p> <p>Replace</p> <p>Replace</p>

Trouble	Probable causes	Remedies
Winker lamp inoperative	<ol style="list-style-type: none"> Winker lamp switch <ul style="list-style-type: none"> Poor contact of winker relay Open circuit in winker relay coil Bulb <ul style="list-style-type: none"> Bulb wattage is smaller than rated wattage Relay <ul style="list-style-type: none"> Poor contact of winker relay Improperly connected leads 	<p>Replace</p> <p>Replace</p> <p>Replace</p> <p>Replace</p> <p>Replace</p>
No charging	<ol style="list-style-type: none"> Broken wire or shorted, loose connection Faulty coil due to short or grounding Faulty or shorted silicon diode Broken or shorted lead wire at regulator Regulator voltage at no load is too low 	<p>Repair or replace</p> <p>Replace</p> <p>Replace</p> <p>Repair or replace</p> <p>Readjust</p>
Insufficient charging	<ol style="list-style-type: none"> Wiring <ul style="list-style-type: none"> Broken wire, intermittent shorting or loose connection Generator <ul style="list-style-type: none"> Shorting across layer in the field coil (resistance indicated in continuity test) Shorting across layer in stator coil Open circuit in one of the stator coil Faulty or shorted silicon diode Regulator <ul style="list-style-type: none"> Voltage below specified value at no load Dirty or pitted points Coil or resistor internally shorted Battery <ul style="list-style-type: none"> Low electrolyte level Defective battery plates 	<p>Repair, retighten</p> <p>Replace</p> <p>Replace</p> <p>Replace</p> <p>Replace</p> <p>Readjust</p> <p>Polish or replace</p> <p>Replace</p> <p>Add distilled water</p> <p>Replace</p>
Excessive charging	<ol style="list-style-type: none"> Wiring <ul style="list-style-type: none"> P terminal circuit and F terminal circuit shorted resulting in split wound generator Battery <ul style="list-style-type: none"> Internal short Regulator <ul style="list-style-type: none"> Excessive voltage at no load voltage Improper grounding Broken coil lead wire 	<p>Repair</p> <p>Replace</p> <p>Repair</p> <p>Provide proper ground</p> <p>Repair, replace</p>
Unstable charging voltage	<ol style="list-style-type: none"> Wiring <ul style="list-style-type: none"> Bare wire shorting intermittently under vibration or broken wire making partial contact Generator <ul style="list-style-type: none"> Layer short (intermittent shorting) Generator <ul style="list-style-type: none"> Intermittent open circuit in the coil Improperly adjusted voltage Defective key switch Dirty points 	<p>Repair or replace</p> <p>Repair or replace</p> <p>Repair or replace</p> <p>Readjust</p> <p>Replace</p> <p>Clean</p>

Trouble	Probable causes	Remedies
Self discharge Battery discharges in addition to that caused by the connected load.	<ol style="list-style-type: none"> 1. Dirty contact areas and case. 2. Contaminated electrolyte or electrolyte excessively concentrated. 	<ol style="list-style-type: none"> 1. Always maintain the exterior clean. 2. Handle the replenishing electrolyte with care.
C. Large discharge rate Specific gravity gradually lowers and around 1.100 (S.G.), the winker and horn no longer function.	<ol style="list-style-type: none"> 1. The fuse and the wiring are satisfactory, but loads such as winker and horn do not function. In this condition the motorcycle will operate but with long use, both \oplus and \ominus plates will react with the sulfuric acid and form lead sulfide deposits, (sulfation) making it impossible to recharge. 	<ol style="list-style-type: none"> 1. When the specific gravity falls below 1,200 (20°C: 68°F), the battery should be recharged immediately. 2. When the battery frequently becomes discharged while operating at normal speed, check the generator for proper output. 3. If the battery discharges under normal charge output, it is an indication of overloading, remove some of the excess load.
High charging rate The electrolyte level drops rapidly but the charge is always maintained at 100% and the condition appears satisfactory. (Specific gravity over 1.260)	<ol style="list-style-type: none"> 1. The deposit will heavily accumulate at the bottom and will cause internal shorting and damage the battery. 	<ol style="list-style-type: none"> 1. Check to assure proper charging rate.
Specific gravity drop Electrolyte evaporates	<ol style="list-style-type: none"> 1. Shorted. 2. Insufficient charging. 3. Distilled water overfilled. 4. Contaminated electrolyte. 	<ol style="list-style-type: none"> 1. Check specific gravity measurement. 2. If the addition of distilled water causes a drop in specific gravity, add sulfuric acid and adjust to proper value.
Sulfation The electrode plates are covered with white layer or in spot.	<ol style="list-style-type: none"> 1. Charging rate is too small or else excessively large. 2. The specific gravity or the mixture of the electrolyte is improper. 3. Battery left in a discharge condition for a long period. (left with the switch turned on) 4. Exposed to excessive vibration due to improper insulation. 5. Motorcycle stored during cold season with battery connected. 	<ol style="list-style-type: none"> 1. When motorcycle is in storage, the battery should be recharged once a month even though the motorcycle is not used. 2. Check the electrolyte periodically and always maintain the proper level. 3. In a lightly discharged condition, perform recharging and discharging several times by starting the engine may be sufficient.
Spark plug electrode coated with carbon deposit	<ol style="list-style-type: none"> 1. Too rich a fuel. 2. Excessive idle speed. 3. Poor quality gasoline. 4. Clogged air cleaner. 5. Use of cold spark plug. 	Adjust carburetor. Adjust idle speed. Use good quality gasoline. Service the air cleaner. Use proper heat range plug.
Spark plug electrode fouled with oil	<ol style="list-style-type: none"> 1. Worn piston ring. 2. Worn piston and cylinder. 3. Excessive clearance between valve guide and valve stem. 	Replace piston ring. Replace piston or cylinder. Replace valve guide or valve.
Spark plug electrode overheated or burnt	<ol style="list-style-type: none"> 1. Use of hot spark plug. 2. Engine overheating. 3. Improper ignition timing 4. Loose spark plug or damaged spark plug hole thread. 5. Too lean a fuel mixture. 	Use proper heat range plug. Readjust ignition timing. Retighten plug or replace cylinder head. Adjust carburetor.
Damage	Spark plug overtightened.	Replace with a new spark plug.