



HONDA
CB750A

9. OIL PUMP / REGULATOR VALVE

SERVICE INFORMATION	9—1	● OIL PUMP ASSEMBLY	9—3
TROUBLESHOOTING	9—1	● REGULATOR VALVE	9—4
LUBRICATION DIAGRAM	9—2	INSPECTION	9—5
DISASSEMBLY/ ASSEMBLY	9—3	ENGINE OIL PRESSURE TEST	9—6

● SERVICE INFORMATION

SPECIFICATIONS

Unit: mm (in.)

Item	Standard	Service Limit
OIL PUMP		
Oil pump body to rotor radial clearance	0.15—0.22 (0.0059—0.0087)	0.35 (0.0138)
Oil pump tip clearance	0.15 (0.0059) max.	0.20 (0.0079)
Oil pump body to rotor clearance	0.02—0.06 (0.0008—0.0024)	0.08 (0.0031)
Relief valve to body clearance	0.025—0.07 (0.001—0.0028)	0.1 (0.004)

TORQUE VALUE

Oil drain bolt 3.5—4.5 kg·m (25.3—32.5 lbs.-ft.)


● TROUBLESHOOTING

SYMPTOM

POSSIBLE CAUSE

(Engine)

Engine overheats



Defective oil pump
Clogged oil passage
Clogged oil filter screen
Clogged oil strainer
Insufficient oil or use of improper oil

Engine stops suddenly
(Engine seized)


(Transmission)

Engine turns, but motorcycle will not
start (in L and D)




Defective oil pump (broken rotor pin or worn rotor)

Engine turns, but motorcycle will not
start (in L and D) (starts slowly when
throttle is opened)



Insufficient oil
Clogged oil strainer
Defective regulator valve (stuck or broken spring)

Poor acceleration at start (in L and D)
or high speed.





Engine revs up at quick start





OIL PUMP/REGULATOR VALVE


● LUBRICATION DIAGRAM







● **DISASSEMBLY/ASSEMBLY**

● **OIL PUMP ASSEMBLY**




(1) Remove the three screws attaching the left side case and remove the case assembly.



J393529



● **OIL PUMP**



J393531



• REGULATOR VALVE




J393532




● **INSPECTION**

- OIL PUMP BODY-TO-ROTOR
RADIAL CLEARANCE




0.15–0.22 mm (0.0059–0.0087 in.)
Service Limit: 0.35 mm (0.0138 in.)

- OIL PUMP TIP CLEARANCE




0.15 mm (0.0059 in.) max.
Service Limit: 0.20 mm (0.0079 in.)

- OIL PUMP BODY-TO-ROTOR
CLEARANCE



0.02–0.06 mm (0.0008–0.0024 in.)
Service Limit: 0.08 mm (0.0031 in.)

- RELIEF VALVE-TO-BODY CLEARANCE




J393530

0.025–0.070 mm (0.001–0.0028 in.)
Service Limit: 0.1 mm (0.004 in.)

**● ENGINE OIL PRESSURE TEST**

OIL PRESSURE:
3.5–4.5 kg/cm² (50–64 psi.) at 3,000 rpm.



- (1) Place the motorcycle on its center stand and apply the parking brake.
- (2) Warm up the engine until the idle speed stabilizes.
- (3) Connect an oil pressure gauge and tachometer.
- (4) Start the engine.
- (5) Keep the engine speed at 3,000 rpm.
- (6) Check the oil pressure in "N" position.



HONDA
CB750A

10. VALVE SHIFT MECHANISM

SERVICE INFORMATION	10-1
TROUBLESHOOTING	10-1
DISASSEMBLY/ ASSEMBLY	10-2
INSPECTION	10-3

● SERVICE INFORMATION

SPECIFICATIONS

Unit: mm (in.)

Item	Standard	Service Limit
Manual valve to manual valve shaft clearance	0.015-0.045 (0.0006-0.0018)	0.1 (0.004)

TORQUE VALUES

Ratchet guide tightening nut	1.0-1.4 kg-m (7.2-10.1 lbs.-ft.)
Shift pivot bolt	2.3-2.7 kg-m (16.6-19.5 lbs.-ft.)

● TROUBLESHOOTING

SYMPTOM

Engine turns, but motorcycle will not start

Hard shifting

Shift pedal not returned

Transmission jumping out of gears

POSSIBLE CAUSE

Broken shift valve pin

Worn ratchet guide

Defective clutch ("L" and "D")

Broken return spring




Shift spindle and case binding

Defective neutral return mechanism



● DISASSEMBLY/ASSEMBLY



- (1) Remove the shift pedal, neutral return arm and cover.





● **INSPECTION**

● **MANUAL VALVE-TO-SHAFT CLEARANCE**



(A) — (B) Difference between (A) and (B)

0.015—0.045 mm (0.0006—0.0018 in.)
Service Limit: 0.10 mm (0.004 in.)

● **CHANGE SWITCH**

Change switch inspection page 14—14.

VALVE SHIFT MECHANISM



HONDA
CB750A

11. TRANSMISSION/CLUTCH

SERVICE INFORMATION	11-1
TROUBLESHOOTING	11-1
DISASSEMBLY/ ASSEMBLY	11-2
● CRANKCASE	11-2
● TRANSMISSION	11-3
● LOW/DRIVE CLUTCHES	11-4
INSPECTION	11-6

● SERVICE INFORMATION

SPECIFICATIONS

Unit: mm (in.)

Item	Standard	Service Limit
L/D clutch initial clearance	0.5-0.8 (0.020-0.031)	—
Clutch return spring free length	39.7 (1.56)	36.0 (1.42)
Clutch disc thickness	1.95-2.05 (0.0768-0.0807)	1.9 (0.075)
Clutch plate thickness	1.95-2.05 (0.0768-0.0807)	1.9 (0.075)
Clutch end plate thickness (1)	1.8 (0.071)	1.6 (0.063)
(2)	2.1 (0.083)	1.9 (0.075)
(3)	2.4 (0.094)	2.2 (0.087)
(4)	2.7 (0.106)	2.5 (0.098)
(No mark)	3.0 (0.118)	2.8 (0.110)
(6)	3.3 (0.130)	3.1 (0.122)

TORQUE VALUES

Crankcase bolt (8 mm)	2.0-2.5 kg-m (14.5-18.1 lbs.-ft.)
Crankcase bolt (6 mm)	1.0-1.4 kg-m (7.2-10.1 lbs.-ft.)

SPECIAL TOOL

CLUTCH SPRING COMPRESSOR 07960-6120000

● TROUBLESHOOTING

SYMPTOM

Motorcycle will not start in "L"
(start in "D")

Motorcycle will not start in "D"
(start in "L")

Poor acceleration at start in "L"

Poor acceleration at start in "D"

POSSIBLE CAUSE

Damaged "L" gears

Defective "L" clutch

Damaged "D" gears


Defective "D" clutch




● DISASSEMBLY/ASSEMBLY

● CRANKCASE

(1) Remove the engine parts as shown.




(2) Remove the upper engine bolts as shown.



(3) Remove the lower engine bolts as shown.

NOTE

During reassembly, apply a coat of liquid sealant. Evenly coat the lower case surface.



TIGHTENING TORQUE


8 mm:	2.0–2.5 kg-m (14.5–18.1 lbs.-ft.)
6 mm:	1.0–1.4 kg-m (7.2–10.1 lbs.-ft.)



• TRANSMISSION



Lubricate all parts with
oil before reassembly.




11 CLUTCH REMOVAL SEQUENCE

TRANSMISSION/CLUTCH

HONDA
CB750A



• LOW/DRIVE CLUTCHES



• REMOVE CLUTCH PISTON

(1) Install the tool.




(2) Compress the clutch return spring.



(3) Remove the snap ring.




(4) Remove the clutch piston as shown.



• INSTALL CLUTCH PISTON

NOTE

Lubricate O-ring thoroughly prior to installing clutch piston.



Apply pressure and rotate to ensure proper seating



● CLUTCH DISC PLATE ASSEMBLY

Measure clearance between the clutch end plate and top clutch disc.



NOTE

Take care not to damage the friction disc when measuring the clutch end clearance.

Service Limit: 0.5–0.8 mm (0.020–0.031 in.)

If not within service limit, select a new clutch end plate from the following table.

Part No.	Plate No.	Thickness
22551–612–000	1	1.8 mm (0.071 in.)
22552–612–000	2	2.1 mm (0.083 in.)
22553–612–000	3	2.4 mm (0.094 in.)
22554–612–000	4	2.7 mm (0.106 in.)
22555–612–000	no mark.	3.0 mm (0.118 in.)
22556–612–000	6	3.3 mm (0.130 in.)




Check the clutch engagement by directing air pressure to an oil passage in the clutch drum hub. Remove the air pressure and check that the clutch is released.




● INSPECTION

● NEEDLE BEARING

Inspect for galling, damaged rollers, and freedom of movement.




● BALL BEARING



Replace if excessively worn.


● MAINSHAFT/GEARS/STATOR SHAFT/ INPUT SHAFT/COUNTERSHAFT






• CLUTCH RETURN SPRING FREE LENGTH

• CLUTCH DISC THICKNESS




39.7 mm (1.56 in.)
Service Limit: 36.0 mm (1.42 in.)




1.95–2.05 mm (0.0768–0.0807 in.)
Service Limit: 1.9 mm (0.075 in.)

• CLUTCH PLATE THICKNESS

• CLUTCH END PLATE THICKNESS




1.95–2.05 mm (0.0768–0.0807 in.)
Service Limit: 1.9 mm (0.075 in.)



Part No.	Thickness	Service Limit
1	1.8 mm (0.071 in.)	1.6 mm (0.063 in.)
2	2.1 mm (0.083 in.)	1.9 mm (0.075 in.)
3	2.4 mm (0.094 in.)	2.2 mm (0.087 in.)
4	2.7 mm (0.106 in.)	2.5 mm (0.098 in.)
no mark	3.0 mm (0.118 in.)	2.8 mm (0.110 in.)
6	3.3 mm (0.130 in.)	3.1 mm (0.122 in.)

**TRANSMISSION/CLUTCH**

- CLUTCH AND RELATED PARTS





HONDA
CB750A

12.

CRANKSHAFT/CONNECTING ROD/PRIMARY SHAFT/ KICK STARTER

SERVICE INFORMATION	12—1	● MAIN BEARING	12—5
TROUBLESHOOTING	12—1	● PRIMARY SHAFT	12—6
DISASSEMBLY/ASSEMBLY		● PRIMARY KICK	12—6
● CONNECTING ROD	12—4	INSPECTION	12—7
BEARING	12—5		

● SERVICE INFORMATION

SELECTION OF BEARING AND INSPECTION OF OIL CLEARANCE

1. Always check the oil clearance after installing a new bearing.
2. Use a chamois or lint-free cloth to clean the bearings.
3. When installing a bearing, align the tab with the groove in the crankcase.
4. Tighten the bearing cap in the correct sequence and to the correct torque.
5. Do not file or sand the crankshaft journals and crankpins.
6. When installing the bearings, apply clean engine oil or molybdenum disulfide base grease.
7. After installing the connecting rods and crankcase, check that the crankshaft rotates freely.
8. After assembling, check the engine idle speed.

SPECIFICATIONS

Unit: mm (in.)

Item	Standard	Service Limit
Crankshaft runout	0.03 (0.0012)	0.05 (0.002)
Crankshaft journal out of round	0.005 (0.0002)	0.010 (0.0004)
Crankshaft journal taper	0.005 (0.0002)	0.010 (0.0004)
Crankshaft journal oil clearance	0.02—0.04 (0.0008—0.0016)	0.08 (0.0031)
Crankshaft journal O.D.	35.99—36.00 (1.4169—1.4173)	35.94 (1.415)
Crankpin O.D.	35.99—36.00 (1.4169—1.4173)	35.94 (1.415)
Connecting rod small end oil clearance	0.02—0.04 (0.0008—0.0016)	0.08 (0.0031)
Connecting rod side clearance	0.15—0.30 (0.0059—0.0118)	0.40 (0.0157)

TORQUE VALUES

Connecting rod nut	1.8—2.2 kg-m (13.0—15.9 lbs.-ft.)
A.C. generator rotor bolt	10.0—12.0 kg-m (72.3—86.81 lbs.-ft.)

SPECIAL TOOLS

BEARING DRIVER	07947—6340000
----------------	---------------

● TROUBLESHOOTING

SYMPTOM

Engine starts but stops soon

Hard starting

Engine cranks but will not start

POSSIBLE CAUSE


- Burnt main bearing
- Burnt connecting rod
- Main bearing worn or damaged
- Connecting rod worn or damaged
- Crankpin worn
- Connecting rod not installed properly




- MAIN BEARING SIZE NUMBER LOCATION

The crankcase main bearing size numbers are punched on the rear side of the upper crankcase.

A,B,C are given from the left side of the crankcase.



- CRANKPIN SIZE MARK LOCATION



The crankpin size marks are stamped on the side of the crankshaft weight which faces the drive sprocket.

(J) → Shows the crankshaft journals.

L. → Means that the marks A, B... C are given from the left side of crankshaft.



A. → Shows the size of the crankshaft journal located at the extreme left side.

A. → Shows the size of the second crankshaft journal from the left side.

B. → Shows the size of the third crankshaft journal from the left side.

B. → Shows the size of the fourth crankshaft journal from the left side.

C. → Shows the size of the crankshaft journal located at the extreme right side.



• When replacing, select the correct size according to the chart below.

For Assembly of main bearing, refer to page 12-5.

Selection table of crankshaft bearing

(Oil clearance 20~46μ)

Crankshaft Journal allowance 36φ		A	B	C
Crankcase allowance 39φ		0 ~ -0.005	-0.005 ~ -0.010	-0.010 ~ -0.015
C	+0.024 +0.016	B (BROWN)	B (BROWN)	A (BLACK)
B	+0.016 +0.008	C (GREEN)	C (GREEN)	B (BROWN)
A	+0.008 0	D (YELLOW)	D (YELLOW)	C (GREEN)

NOTE

When assembling, use the main bearing having the same mark.




HONDA
CB750A

CRANKSHAFT/CONNECTING ROD/ PRIMARY SHAFT/KICK STARTER

CONNECTING ROD
BEARING

12

• CRANKPIN INDEX MARK LOCATION




The crankpin index marks are stamped on the left side of the crankshaft weight and is located in the same position as the crankshaft journal size marks.

(P): Shows the crankpin

L: Means that the marks 3.4 - - - 4 are given from the left side of crankshaft.

3434: Shows the sizes of the crankpins from the left side.


• WEIGHT IDENTIFICATION OF CONNECTING RODS



- If connecting rod replacement is necessary, determine and record each connecting rod weight mark. Then, select the connecting rod bearings having the same weight mark.

Weight I.D. mark

MARK	PARTS NO.
D	13204-300-000
F	13206-300-000
J	13208-300-000




- When replacing, select the same mark of the connecting rod and the proper metal according to the charts given below.
For assembly of connecting rod bearing, refer to page 12-5.

Selection table of connecting rod bearing

(Oil clearance 20~46μ)

Crank pin allowance 36φ		3	4	5
Connecting rod allowance 39φ		0 ~ -0.005	-0.005 ~ -0.010	-0.010 ~ -0.015
3	+0.024 +0.016	B (BROWN)	B (BROWN)	A (BLACK)
2	+0.016 +0.008	C (GREEN)	C (GREEN)	B (BROWN)
1	+0.008 0	D (YELLOW)	D (YELLOW)	C (GREEN)




NOTE

When assembling, use the connecting rod bearing having the same mark.




●DISASSEMBLY/ASSEMBLY

- (1) Remove the lower crankcase.
- (2) Remove the cylinder and the pistons.
- (3) Remove the A.C. generator.



NOTE

When replacing the bearing, select the correct bearing so that the I.D. mark of the crankshaft corresponds to the connecting rod.


**• CONNECTING ROD BEARING ASSEMBLY****NOTE**

Do not rotate the crankshaft during the inspection and tighten connecting rod cap, to the specific torque.

- (1) Remove the caps and bearings.
- (2) Lay a strip of plastigage lengthwise on the crankpin.
- (3) Install the cap and tighten the cap nuts to 1.8–2.2 kg-m (13.0–15.9 lbs-ft.)
- (4) Remove the cap and measure the amount of widest flattening with the scale printed on the gauge bag.

Bearing Clearance	Standard 0.02–0.04 mm (0.0008–0.0016 in.)
	Service Limit 0.08 mm (0.0031 in.)

* If the bearing clearance is beyond the tolerance, check the connecting rod and crankpin for wear. If they are not worn, replace the bearings with the undersize bearing and recheck the clearance.

• MAIN BEARING ASSEMBLY**NOTE**

Do not rotate the crankshaft during the inspection and tighten each nut in X pattern to the specific torque.


- (1) Remove the caps and bearings.
- (2) Lay a strip of plastigage lengthwise on the crankshaft journal. Install crankshaft.
- (3) Install the lower crankcase. Install the crankcase bolts, tightening to 2.3–2.5 kg-m (16.6–18.1 lbs-ft.).
- (4) Remove the lower crankcase and measure the amount of widest flattening with the scale printed on the gauge bag.

Bearing Clearance	Standard 0.02–0.04 mm (0.0008–0.0016 in.)
	Service Limit 0.08 mm (0.0031 in.)

* If the bearing clearance is beyond tolerance, check the crankcase and journal for wear. If they are not worn, replace the bearings with the undersize bearings and recheck the clearance.




• PRIMARY SHAFT




• PRIMARY KICK

• DISASSEMBLY




• ASSEMBLY





● INSPECTION


● CRANKSHAFT RUNOUT




CRANKSHAFT RUNOUT

0.03 mm (0.0012 in.)
Service Limit: 0.05 mm (0.002 in.)

TAPER



OUT OF ROUND



CRANKSHAFT JOURNAL/CRANKPIN O.D.

35.99–36.00 mm (1.4169–1.4173 in.)
Service Limit : 35.94 mm (1.415 in.)


CRANKSHAFT JOURNAL TAPER

0.005 mm (0.0002 in.)
Service Limit: 0.010 mm (0.0004 in.)

CRANKSHAFT JOURNAL OUT OF ROUND

0.005 mm (0.0002 in.)
Service Limit: 0.010 mm (0.0004 in.)

● CONNECTING ROD SIDE CLEARANCE



0.15–0.30 mm (0.0059–0.0118 in.)
Service Limit: 0.40 mm (0.0157 in.)

Replace with a new one, if it is out of limit.

CRANKSHAFT/CONNECTING ROD/
PRIMARY SHAFT/KICK STARTER

HONDA
CB750A





HONDA
CB750A

13. CARBURETOR

SERVICE INFORMATION	13—1	● FLOAT HEIGHT	13—5
TROUBLESHOOTING	13—1	● ACCELERATOR PUMP	13—6
DISASSEMBLY/ ASSEMBLY	13—2	● IDLE MIXTURE	13—7
ADJUSTMENT	13—5	● ALTITUDE ADJUSTMENT	13—7
		INSPECTION	13—8

● SERVICE INFORMATION

CARBURETOR SETTING CHART

		'76 model	'77 model	'78 model
Item	Setting No.	PD44A	PD44B	PD43A
Standard main jet No.		102	108	←
Standard slow jet No.		38	←	←
Standard air jet No.		150	200	200
Standard slow air jet No.		150	←	←
Standard jet needle setting		3rd notch	←	—
Pilot screw opening		1 1/4 turn	1 turn	1 1/8 turn
Float height		14.5 mm (0.571 in.)	12.5 mm (0.492 in.)	←
Idle speed		950 ± 100 rpm/N	←	←

● TROUBLESHOOTING

● Engine Cranks But Won't Start

1. No fuel in tank
2. No fuel getting to cylinders
3. Too much fuel getting to cylinders
4. No spark at plugs — (ignition malfunction)
5. Air cleaner clogged

● Engine Idles Roughly, Stalls, or Runs Poorly

1. Idle speed incorrect
2. Ignition malfunction
3. Low compression
4. Rich mixture
5. Lean mixture
6. Air cleaner clogged
7. Air leaking into manifold
8. Fuel contaminated
9. Carburetors not synchronized

● Lean Mixture

1. Carburetor fuel jets clogged
2. Throttle valve stuck closed
3. Fuel cap vent blocked
4. Fuel filter clogged
5. Fuel line kinked or restricted
6. Float valve faulty
7. Float level too low

● Rich Mixture

1. Choke stuck closed
2. Float valve defective
3. Float level too high
4. Carburetor air jets clogged



● DISASSEMBLY/ASSEMBLY

WARNING

Gasoline is flammable.
Keep spark and open flame away from carburetor during disassembly/assembly.

(1) Remove the carburetor assembly.

NOTE

Replace with a new one, when disassembled.

(10) No. 4 CARBURETOR

THROTTLE LINE

(4) REAR STAY

(11) No. 3 CARBURETOR

CHOKE LINK

(6) TOP/LINK ARM

(3) THROTTLE
OPENER

NOTE

Never disassemble.

(2) THROTTLE
RETURN
SPRING

(8) No. 1
CARBURETOR

SOLENOID
VALVE

(9) No. 2 CARBURETOR

(7) CHOKE VALVE
PLATE

(5) STAY PLATE

NOTE

Clean carburetor body, jets and all parts with compressed air before assembling.

Perform the following inspections and adjustment after assembly:

- Choke and throttle valve operation check Page 4-10, 13
- Throttle grip free play adjustment Page 4-10
- Carburetor synchronization Page 4-14



• CARBURETOR


- 1 Remove the choke valve and the setting screw of the link arm.
- 2 Remove the stay plate after removing the return spring.
- Replace the choke valve set screws with bolts and lock washers.
- Check the operation of the choke valve after assembling. Raise the tab of the lock washer.

CHOKE VALVE

NOTE


Note the installation direction.

Replace the bolt and washer when disassembled.



NOTE

Before loosening the screws, file off the staked areas and wipe clean.



NOTE

At time of assembly, replace.

K410-599


• No. 2 CARBURETOR INSTALLATION

NOTE

- Drive the stopper pin out with a hammer and punch.
- Replace the stopper pin with a new one.

• No. 3 CARBURETOR REMOVAL

Remove the Carburetor after removing the throttle link stopper pin.



NOTE

Do not forget to install.

AIR THROUGH HOLE

NOTE

Bend the lever end after installing the cable.

NOTE

Do not forget to install.

NOTE

Temporarily wind the spring one turn.

Place in V blocks.


K410597

K410-604




• FLOAT CHAMBER

Remove the carburetor assembly.



• THROTTLE VALVE


Remove the carburetor assembly.





• **FLOAT, FLOAT VALVE AND JETS**


- (1) Remove the carburetor.
- (2) Remove the float chamber.
- (3) Remove the throttle valve.



• **ADJUSTMENT**

• **FLOAT LEVEL INSPECTION AND ADJUSTMENT**


Place the carburetor as shown.



FLOAT LEVEL

'76 model	14.5 mm (0.571 in.)
'77 and '78 models	12.5 mm (0.492 in.)

If out of specification, adjust the float level by bending the float arm.






• ACCELERATOR PUMP

PUMP ROD-TO-PUMP ARM CLEARANCE

- (1) Remove the carburetor.
- (2) Close the throttle valve.
- (3) Measure the clearance.




- (4) To adjust, bend the pump arm tongue.

PUMP ARM-TO-CARBURETOR STAY CLEARANCE

- (1) Remove the carburetor.
- (2) Close the throttle valve.
- (3) Measure the clearance.

- (4) To adjust, bend the pump arm.





• PILOT SCREW INITIAL SETTING

Turn the pilot screw clockwise with a screwdriver until it seats lightly, and back it out to specified opening turns.

SPECIFIED OPENING:

'76 MODEL—1-1/4 TURNS OUT


'77 MODEL—1 TURN OUT

'78 MODEL—1-1/8 TURNS OUT

This is a preliminary setting prior to final Pilot Screw Adjustment.


CAUTION

Damage to the pilot screw seat will occur if the pilot screw is tightened against the seat.



• PILOT SCREW ADJUSTMENT

- (1) Place the motorcycle on its center stand and set the parking brake.
- (2) Warm up the engine to operating temperature. Stop-and-go driving for approx. 10 minutes should be sufficient.
- (3) Connect a tachometer.
- (4) Adjust the idle speed with the throttle stop screw.
IDLE SPEED: 950 ± 100 rpm (IN NEUTRAL)
- (5) Turn the No. 2 carburetor pilot screw in or out to obtain the highest engine speed.
- (6) Readjust the idle speed with the throttle stop screw.
- (7) Perform steps (5) and (6) to remaining carburetors.






● INSPECTION

● SOLENOID VALVE INSPECTION

Check the operation of the solenoid. The solenoid is normal if there is air flow from (A) to (C), or there is no air flow from (C) to (B), when it is energized. No air should flow from (A) to (B), or air should flow from (B) to (C) when the solenoid is de-energized.



● CHECK VALVE

Air should flow from (A) to (B).
No air should flow from (B) to (A).

