

15. INDEX

— A —	
Adjust ignition timing	11
— valve tappet clearance.....	7
— cam chain	13
— carburetor	8
Alternator generator	93
Air cleaner	16, 119
— B —	
Battery	102
Bleeding brake system	15, 73
Brakes	65
Brake caliper adjustment	14
Brake lever travel	72
Brake pedal travel	15
Brake lining wear mchitor	112
Body electrical	87
Body	84
Bore and stroke.....	115
Blow-by gus	108
Bulb	116
— C —	
Cam chain tensioner	13, 46
Carburetor	57
Camshaft	24
— holder.....	24
Charging system	93
Change oil and oil filter	13
Clutch	40, 107, 115
Compression ratio	115
— test	17
— pressure	17
Condenser	92
Connecting rod	51
Contact breaker	92
Crankshaft	48
Cylinder	24
— arrangement	24
— bore	27
Cylinder head	24
— D —	
Displacement	115
Drive chain	16
— E —	
Engine installation	20

Engine removal	20
— F —	
Final drive	56
Final reduction	56
Front brake	65
Front suspension	79, 110
Front wheel and tire.....	65
Fuel tank capacity	115
Fuel strainer.....	85
Fuel tank	84
— G —	
Gear ratio	116
Gear shift drum	43
Gear shift drum stopper	43
Generator	95
— H —	
Horn.....	107
— I —	
Idling speed	9
Ignition timing	11
Ignition system	89
Ignition coil	89
— K —	
Kick starter pedal	53
— L —	
Lubrication system	36
— M —	
Main ignition switch	107
Maintenance operation	7
— N —	
Neutral switch	106
— O —	
Oil filter	14, 39
— element	14
Oil pump	39
Oil pressure switch	105
Oil warning lamp	87
Oil screen	37
Oil drain plug	20

— P —	
Piston	27
Piston pin	26
Piston ring	28
Primary chain	48
Primary shaft	54
— R —	
Rear brake	15, 73
Rear suspension	82
Rear fork	82
Rear wheel	73
Regulator	96
Relief valve	37
Rocker arm	35
— shaft	35
— S —	
Service air cleaner	85
— battery	16, 102
— spark plug	13, 91
Special tools	3
Silicone rectifier	97
Spark advancer	92
Spark plug	13, 91
Specifications	115
Starting clutch.....	48
Starter magnetic switch	101
Starting motor.....	99
Starting moter safety unit	109
— cable	99
Steering	77
Stop switch.....	107
— T —	
Technical data	115
Throttle valve	61
Trouble shooting	107
Transmission.....	37
— V —	
Valve	34
Vacuum gauge.....	5
Valve timing	31
— W —	
Winker switch	104
Wiring diagram.....	119